

7.3 Meter Ka-Band Broadband Gateway Earth Station Antenna Model VA-7.3-KA

Technical Manual

Original Instructions

Manual Part Number 1175567 Revision 001 August 2013

EXPORT CONTROL NOTICE

This technical data is subject to the United States Export Administration Regulations. Diversion contrary to US law is prohibited.

PROPRIETARY NOTICE

The information contained in this manual including text, illustrations, drawings, lists or specifications are the confidential information and/or trade secrets of ViaSat, Inc., and issued in strict confidence. Except as authorized by ViaSat in writing, this manual shall not be reproduced, retransmitted, used for the design, manufacture or sale of equipment or used for any other purposes other than the evaluation, operation and/or maintenance of the subject equipment or system.

www.viasat.com



Notice

All Rights Reserved

The information in this document is subject to change without notice. ViaSat, Inc. assumes no responsibility for any errors that may appear in this document and does not warranty any specific application.

Any product names mentioned herein are used for identification purposes only, and may be trademarks and/or registered trademarks of their respective companies.

In all correspondence with ViaSat, Inc. regarding this publication, please refer to the Manual Part Number and Revision printed on the title page.

No part of this book may be reproduced in any form or by any means without permission in writing from ViaSat, Inc.

Copyright ® 2013 ViaSat, Inc.

All rights reserved.

ViaSat Inc. Headquarters ViaSat Inc. ViaSat Antenna Systems

6155 El Camino Real 1725 Breckinridge Plaza

Carlsbad, CA 92009 Duluth, GA 30096

USA USA

Tel: +1 760-476-2200 Tel +1 678-924-2400

Fax: +1 760-929-3941 Fax +1 678-924-2480



Table of Contents

Table o	of Contents	iii
List of 1	Figures	iv
List of	Tables	iv
Safety S	Summary	V
-	viations	
Genera	l Information	1-1
1.1	Introduction	1-1
1.2	Contents of the Manual	1-1
1.3	Change Recommendations	1-1
1.4	Antenna Description	1-1
1.4.1	Reflector	1-2
1.4.2	Subreflector	1-3
1.4.3	Feed Assembly	1-3
1.5	Specifications	1-4
1.6	Safety Guidelines	1-4
1.6.1	Emergency Plan	1-4
1.6.2	Resuscitation	1-4
1.6.3	General Mechanical Safety	1-5
1.6.4	General Electrical Safety	1-5
1.7	Operation	1-5
1.8	Maintenance	1-6
1.9	Repairs	1-7
1.9.1	Feed Window Replacement	1-7
Drawir	ngs and Parts	2-1
2.1	Introduction	2-1
2.2	Drawing and Parts Index	2-2



LIST OF FIGURES

Figure 1-1. 7.3 Meter Ka-Band Broadband Gateway Earth Station Antenna	1-2
Figure 1-2. Feed Window	1-8
LIST OF TABLES	
Table 1-1. Antenna Specifications	1-4
Table 1-2. Routine Inspections	1-6
Table 2-1. Drawings and Parts Index	2-2



SAFETY SUMMARY

Notice

Any service, adjustment, maintenance, or repair of this product must be performed only by authorized technical service personnel.

Prior to installation and use of this product review all safety markings and instructions. When safety precautions or important information is presented in this manual, the information will normally be presented just prior to the point where the hazard is likely to be encountered.

The following symbols are used throughout this manual to bring attention to practices, procedures, and conditions important to the safety of the operator and equipment or to obtaining desirable results from the equipment.



WARNING

This symbol warns of electrical shock hazards to personnel. Failure to comply with the instructions of such a warning may result in severe injury or death resulting from electrical shock.



WARNING

This symbol warns of non-electrical hazards to personnel. Failure to comply with the instructions of such a warning may result in severe injury or death.



This symbol warns of inhalation hazard where toxic fumes or vapors, especially carbon monoxide, may be present. Failure to comply with the instructions of such a warning may result in severe injury or death resulting from inhaling toxic vapors or fumes.



CAUTION

This symbol warns of hazards to equipment. Failure to comply with the instructions of such a caution may result in damage or destruction of equipment.



CAUTION

This symbol warns of possible Electrostatic Discharge damage to equipment. Use a wrist grounding strap connected to the ground to prevent Electro Static Discharge damage to electronic components.



GROUNDING REQUIRED

This symbol is used to bring attention to installation grounding requirements.

NOTE

Notes are used to provide clarification, or to alert the reader of possible erroneous results, which may occur if a procedure is not followed as written.



ABBREVIATIONS

The following list defines symbols and abbreviations used in this manual.

Symbol or Abbreviation	Definition
0	Degrees
AZ	Azimuth
BOM	Bill of Material
С	Celsius
CW	Clockwise
dB	Decibel
EIRP	Effective Isotropic Radiated Power
EL	Elevation
G/T	Gain-to-noise Temperature
GHz	Gigahertz
НРА	High Power Amplifier
ITU-R	International Telecommunication Union - Radiocommunication Sector
km/h	Kilometers per hour
LHC	Left Hand Circular
LHCP	Left Hand Circular Polarization
LNA	Low Noise Amplifier
m	Meter
M&C	Monitor and Control
Mph	Miles per hour
PSIG	Pound-force per Square Inch Gauge
RF	Radio Frequency
RHC	Right Hand Circular
RHCP	Right Hand Circular Polarization
RMS	Root mean square
RX	Receive
TX	Transmit



Chapter 1

General Information

1.1 Introduction

This manual provides information about the 7.3 Meter Ka-Band Broadband Gateway Earth Station Antenna.

1.2 Contents of the Manual

This manual consists of the following chapters:

Chapter 1 - General Information

Chapter 2 - Drawings and Parts

1.3 Change Recommendations

Submit recommendations concerning changes to Technical Publications Manager, ViaSat, Antenna Systems, 1725 Breckinridge Plaza, Duluth, Georgia 30096.

1.4 Antenna Description

The antenna consists of a 7.3m reflector with a Cassegrain subreflector, Ka-band feed, 4-port diplexer, and on Autotrack systems, a TE21 coupler. The antenna provides Right Hand Circular Polarized (RHCP) and Left Hand Circular Polarized (LHCP) ports for the simultaneous transmission and reception with the satellite. On Autotrack antennas, there are two additional output ports from a TE21 mode coupler supplying automatic tracking capability in RHCP and LHCP modes. Tracking polarization is selectable.

The antenna includes the following main components:

- Reflector
- Subreflector
- Feed Assembly






Figure 1-1. 7.3 Meter Ka-Band Broadband Gateway Earth Station Antenna

1.4.1 Reflector

A 7.3m Ka-band reflector provides the requirements of the satellite link. This reflector is a field proven ViaSat product designed specifically for Ka-band applications, and provides excellent RF and mechanical performance. This reflector utilizes a high-efficient, dual-shaped surface profile derived using performance maximizing RF design techniques.

The reflector consists of a large hub, trusses, and panels. The all-aluminum construction eliminates the stresses and distortions due to unequal thermal expansion of different metals. These aluminum parts are treated, primed, and then painted with light-diffusive white paint to minimize the solar furnace effect. The interior of the hub is spacious and is designed specifically for mounting Ka-band RF electronics near the feed while still providing access to components for routine maintenance and replacement. The reflector panels are manufactured using high-precision stretch-form tooling and assembly techniques.

The mechanical structure provides the stiffness required to operate at Ka-band. Since all large aperture Ka-band reflectors require accurate field alignment, ViaSat has developed proprietary photogrammetric techniques to accurately field align the reflector surface to better than 0.2 mm RMS at the operating elevation angle.



1.4.2 Subreflector

The subreflector assembly consists of a machined aluminum subreflector and mount, optimized for high efficiency and antenna performance. The subreflector is supported by four sturdy aluminum spars of rectangular cross sections that are attached to reinforced points on the reflector structure.

1.4.3 Feed Assembly

ViaSat's standard Ka-band Cassegrain four-port circular polarized feed provides optimum performance in the 7.3m reflector to maximize the Gain-to-noise Temperature (G/T) and Effective Isotropic Radiated Power (EIRP).

Key features of the feed assembly include:

- Wideband corrugated horn radiator for optimum gain and sidelobe performance
- 4-port circular polarization transmit/receive diplexer for excellent cross-pol isolation
- Feed interface ports at hub interface to minimize waveguide length to LNAs and HPAs

The wideband corrugated horn operates over the entire Ka-band, and features a symmetrical primary radiation pattern that efficiently illuminates the reflector optics. The horn provides excellent return loss and cross-polarization performance over the entire band. The received signal exits the horn in circular waveguide and passes to the four-port polarization network.

The four-port polarization network separates transmit and receive band signals, and generates both right hand circular (RHC) and left hand circular (LHC) signals for each band. The phase and amplitude characteristics of the four-port network are precisely controlled to produce an axial ratio of less than 0.5 dB (30 dB cross-pol isolation).

The feed horn utilizes a high performance Teflon window material. The Teflon material is mechanically stronger than Mylar to better resist damage from hail and other debris, and the inherent hydrophobic properties of Teflon enable the window to shed water better than Mylar.

High frequency band signals are particularly sensitive to attenuation by water, so it is important to minimize the accumulation of water on the feed aperture. A highly reliable, long-life blower assembly mounted in the reflector back structure area directs air to the feed aperture through an air duct external to the feed assembly. The feed blower assembly, a separate assembly from the antenna, minimizes the effects of precipitation on antenna performance by constantly directing a stream of air across the feed horn aperture to remove rain as well as other debris.

All waveguide and feed components must be pressurized with dry air at a regulated air pressure set to 0.5 PSIG typical. This prevents moisture from entering the waveguides, protects the sensitive Ka-band components from corrosion, and prevents insertion loss degradation.



1.5 Specifications

Table 1-1. Antenna Specifications				
Characteristics	Specification			
Model	VA-7.3-KA			
Antenna diameter	7.3 meters			
Antenna type	Shaped dual reflector			
Polarization	Right Hand Circular Polarization (RHCP) & Left Hand Circular Polarization (LHCP) for both Tx & Rx			
Tracking	Options for Autotrack or Program Track			
Operating frequency	Rx: 17.7-21.2 GHz			
	Tx: 27.0-31.0 GHz			
3 dB beamwidth	Rx: 0.15° nominal			
	Tx: 0.10° nominal			
Axial ratio	0.5 dB maximum			
Radiation patterns	Compliant with ITU-R Rec. S.580-5 and FCC 25.209			
Power handling per Tx port	500 watts CW			
Survival wind	200 km/h in stow position, no icing			
Temperature	-40°C to +55°C			

1.6 Safety Guidelines

Before operating the pedestal, read these safety warnings and perform the following checks.



WARNING

One of the emergency stop switches should always be pressed before working on or near the antenna mount. Failure to comply with this warning can result in serious injury or death.



WARNING

Failure to comply with these instructions may result in damage or destruction of equipment, and severe personnel injury or death.

1.6.1 Emergency Plan

Have an emergency plan. Know the procedures for obtaining first-aid and fire-fighting assistance. Plan your work and maintain good housekeeping.

1.6.2 Resuscitation

Personnel working with or near hazardous chemicals or voltages should be familiar with modern methods of resuscitation.



1.6.3 **General Mechanical Safety**

The following are general mechanical safety precautions not related to any specific procedure.



WARNING

These are recommended precautions that personnel must understand and apply. Death or severe injury may result if personnel fail to observe safety precautions.

- Installation or maintenance of antennas may require persons to work at elevated work stations. Whenever persons are working at eight or more feet above ground and are not on a guarded platform, they should wear safety belts with at least one, and preferably two, lanyards. The exception is trained and qualified persons that may work up to 25 feet (7.6 meters) if on an approved ladder. Approved ladder usually means that the ladder is tied off once the person has climbed but before work begins.
- Never stand underneath anything while it is being hoisted.
- Always wear a hard hat if someone is above you.
- Ensure that all electrical tools and equipment are properly grounded.

1.6.4 General Electrical Safety

The following are general electrical safety precautions not related to any specific procedure. They are recommended precautions that personnel must understand and apply.



- These are recommended precautions that personnel must **WARNING** understand and apply. Death or severe injury may result if personnel fail to observe safety precautions.

- Electrical shock from voltages can cause injury or death. Prior to making any electrical connections or performing maintenance and repair, ensure power is removed. Electrical connections should be made only by qualified personnel in accordance with local regulation.
- Avoid shorting circuits when using metal tools. Some circuits have high current capability that, when shorted, will flash and may cause burns and/or eye injury.
- Remove all jewelry and exposed metal objects from body and clothing before performing maintenance, adjustments, and/or trouble-shooting. Before working inside the equipment, remove all power, unless power is required to perform the procedure. Do not replace parts with power on.
- Replacement of fuses or other parts must be done using identical types and ratings. Substitution of non-identical parts may cause safety and fire hazards.
- Servicing the equipment may require working with protective covers removed and AC power connected. Extreme caution must be exercised during these procedures.

1.7 Operation

Operation of the antenna is integrated into the M&C system.



1.8 Maintenance

Perform the following inspections monthly and repair any noted defects as listed in Table 1-2.

	Table 1-2. Routine Inspections				
Inspection Item	Instruction				
Feed blower	Verify feed blower is operating. Check blower's air filter and replace if dirty.				
Feed pressurization	Verify dehydrators are operating and duty cycle is acceptable. From the ground, observe the feed window. It should have a convex shape when pressurized. Also observe the pressure gauge inside the antenna hub. The regulated air pressure should be set to 0.5 PSIG.				
Galvanized surfaces	Inspect for dirty, blemished, worn, or deeply scratched protective finish. Repair blemished area as follows.				
	 Use a wire brush to remove all paint, corrosion, and/or rust from the blemished area. 				
	2. Clean area with solvents to remove all oils and grease. Wipe dry with a clean cloth.				
	3. Apply "cold-galvanize" paint with a brush to the prepared surface areas. Apply a sufficient quantity to cover and seal repaired surface area.				
	Cold galvanize paint, ViaSat part number 1109690, is supplied as part of ViaSat Paint Touch-Up and Lubrication, Bill of Material 1109398.				
Exposed threaded fasteners and	Inspect for dirt, rust, and/or corrosion. If rusted or corroded, repair blemished area as follows.				
hardware	 Use a wire brush to remove all paint, corrosion, and/or rust from the blemished area. 				
	2. Clean area with solvents to remove all oils and grease. Wipe dry with a clean cloth.				
	3. Apply "cold-galvanize" paint with a brush to the prepared surfaces areas. Apply a sufficient quantity to cover and seal repaired surface area.				
	Cold galvanize paint, ViaSat part number 1109690, is supplied as part of ViaSat Paint Touch-Up and Lubrication, Bill of Material 1109398.				
Painted surfaces	Inspect for dirty, blemished, worn, or deeply scratched protective finish. Repair blemished area as follows.				
	1. Sand or wire brush to remove rust and/or corrosion.				
	Apply paint per manufacturer's instructions to prevent rust or corrosion.				
	3. Use paint touch-up kit provided with the antenna.				
Water drain holes (if applicable)	Inspect drain holes on the bottom reflector panel. Ensure water can drain freely through the openings. If an opening is blocked with debris, use a wooden dowel or rod to clear.				



1.9 Repairs

1.9.1 Feed Window Replacement

It is recommended that the feed window be replaced every 3 to 5 years. Materials required are ViaSat kit PN 442460 and silicon rubber sealant (RTV 3145).

- 1. Position the antenna to a convenient maintenance position.
- 2. Press EMERGENCY STOP switch on antenna pedestal. This prevents the antenna pedestal from moving the antenna during the maintenance.
- 3. Use an aerial lift to excess the feed. Be very careful not to allow the lift to collide with the antenna.




Figure 1-2. Feed Window

- 4. Remove 10-32 screws, lock washers, flat washers and clamp ring shown in Figure 1-2.
- 5. Remove old feed window fabric and film.
- 6. Temporarily cover the open feed horn with a clean lint-free cloth to ensure debris does not enter feed aperture. Carefully remove old silicon sealant from mounting surfaces. Do not scrape or cut away silicon using metal tools that may create metal filings.
- 7. Prepare a new feed window. The window consists of two materials, a polyester film and a hydrophobic fabric. Both are supplied in sheet form in the kit. Use the clamp ring as a template to prepare the film and fabric materials.
- 8. Remove the temporary cover from the feed.



- 9. Carefully apply a small amount of silicon evenly about the entire diameter of the feed cover and place the new polyester film on feed cover.
- 10. Place the new hydrophobic fabric over the polyester firm with the white side facing away from the feed.
- 11. Place clamp ring on feed window and secure with sixteen ½ inch long 10-32 screws, flat washers and split lock washers.
- 12. Tighten all screws evenly to compress the lock washers. Do not over-tighten.
- 13. Trim any excess materials and clean excess silicon from the exterior surfaces.
- 14. Restore and check pressurization.



Chapter 2

Drawings and Parts

2.1 Introduction

Table 2-1 provides a list of drawing and parts applicable to the 7.3 Meter Ka-Band Broadband Gateway Earth Station Antenna. If part information is not on the drawing, a Bill of Material (BOM) report immediately follows the drawing to identify component parts of the assembly.

The following information is included on each Bill of Material report.

Title Block The title block contains the BOM part number, revision number, and

description.

Level Multi-level bill of material reports are formatted to show the relationship of

assemblies, subassemblies, and component parts. The Level column of the

report lists the numerical level of each line item. Level 1 identifies components of the assembly. Level 2 identifies sub-assemblies of the assembly, and level 3 identifies components of the sub-assemblies. Additional levels may be used to indicate subordination as needed.

Ref Des The Ref Des column of the report lists the reference designator used to

identify components on the assembly drawing or schematics.

Part Description The Part Description column of the report provides a brief description of the

item.

Qty The Qty column of the report lists the number of items used in the

assembly.



2.2 Drawing and Parts Index

Table 2-1. Drawings and Parts Index				
Number_Revision	Description	Page		
1102007_004	Assembly/Installation Drawing, Reflector 7.3 m Ka (CHUB)	2-3		
	(Parts list on drawing)			
098984_002 Assembly/Installation Drawing, Subreflector/Spars 7.3 m Ka		2-9		
	(Parts list on drawing)			
1111460_001	Program Track Feed Assembly Drawing	2-13		
1111459_002	Bill of Material, Program Track Feed	2-19		
1091781_003	Autotrack Feed Assembly Drawing	2-20		
1093281_006	Bill of Material, Autotrack Feed	2-26		

8 REVISION HISTORY IN AGILE (ALL SHEETS AT SAME REVISION) ↑↑ TO LIFT THE REFLECTOR ONTO THE MOUNT: DESCRIPTION NOTES: 12 IF THE POSITION OF THE CLEVIS TABS ON THE LOADFRAME DO 004 CO-076293 NOT ALLOW THE 3/4-10 HEX HEAD SCREW, ITEM 121, TO FIT USE • THE REFLECTOR MAY BE LIFTED WITH OR WITHOUT THE SPARS AND 1. INTERPRET DIMENSIONING AND TOLERANCES PER ASME Y14.5M-1994. ITEM 124, 3/4-10 SOCKET HEAD SCREW IN ITS PLACE. SUBREFLECTOR INSTALLED, IF THE SUBREFLECTOR ASSEMBLY IS CUT OR GRIND WASHER, ITEM 221, TO MISS WELD IF REQUIRED. INSTALLED, THE STRAPS MUST BE SPREAD, OR MUST BE LONG THE PARTS LIST ON THIS DRAWING IS PROVIDED TO FACILITATE ASSEMBLY ENOUGH TO AVOID CONTACT WITH THE EDGE OF THE SUBREFLECTOR. AND INSTALLATION, NOT FOR PACKING OR SHIPPING. THE FIND NUMBERS AND QUANTITIES ON THE PARTS LIST ARE INTENDED TO MATCH EXACTLY REMOVE LIFT HOLE COVERS FROM THE 4 EQUALLY SPACED PANELS, THE BALLOONED ITEMS ON THE DRAWING. THE ITEMS ON THE PARTS LIST D ITEM 13, AS SHOWN ON SHEET 4, EXPOSING THE LIFTING TABS. INSTALL MAY BE SHIPPED IN MULTIPLE CRATES OR KITS. EACH WITH THEIR OWN FOUR LIFT BARS FROM THE KIT ITEM 17, ONE AT EACH HUB LIFT TAB, BILL OF MATERIAL (BOM). SOME QUANTITIES ON THE BOMS MAY EXCEED THOSE IN THE PARTS LIST, TO PROVIDE FOR EXCESS, ESPECIALLY OF TO EXTEND UP THROUGH THE HOLE IN THE PANEL. WHEN TORQUING FASTENERS, ASSURE THAT THE BAR CLEARS THE PANEL WHERE IT SMALL FASTENERS. EXTENDS THROUGH THE HOLE. THIS ASSEMBLY DOES NOT INCLUDE A HUB; IT IS SHOWN FOR REFERENCE. ATTACH A SHACKLE AND STRAP TO EACH LIFTING BAR. THE HUB IS SHIPPED AS A SEPARATE SYSTEM LEVEL ITEM. ATTACHMENT OF ITEMS TO THE HUB IS DESCRIBED, AS WELL AS ATTACHMENT OF THE POSITION THE MOUNT ADAPTER FRAME AT 90° ELEVATION, SO THE HUB HUB TO THE MOUNT. ATTACHMENT SURFACE IS LEVEL FOR RECEIVING THE REFLECTOR. THE VIEWS SHOWN ON SHEET 2 ARE INTENDED TO ASSIST IDENTIFICATION • LIFT THE REFLECTOR ONTO THE ADAPTER FRAME, ALIGN THE OF PARTS. MOUNTING HOLES BETWEEN THE FRAME AND THE HUB, AND FASTEN WITH THE HARDWARE SHOWN. <u>√5</u> PERFORM PANEL ALIGNMENT ACCORDING TO PROCEDURE 1102008. SHIM KIT 1074533 IS PROVIDED FOR USE WITH THIS ALIGNMENT PROCEDURE. REINSTALL THE 4 LIFT TAB COVERS PREVIOUSLY REMOVED AFTER REMOVING LIFTING SHACKLES AND STRAPS FROM THE LIFT TABS. 6. FASTENER TORQUE SPECIFICATION FOR THIS ASSEMBLY: 1074533 KIT SHIMS, AL, 9/16 SLOT, 3 X 3, 180 PC SIZE STAINLESS GALVANIZED 44 85839 NUT 3/4-10 UNC-2B HVY HEX GALV 320 1104944 KIT LIFT BAR 1/2-13 55 LBF FT [75 N M] 83 LBF FT [113 N M] 384 356513 NUT 1/2-13 UNC-2B HEX SST 311 530308-024 ROD 1/2-13 X 6.0 SST 3/4-10 195 LBF FT [264 N M] 293 LBF FT [397 N M] 138 85838 NUT 1/2-13 UNC-2B HVY HEX GALV 310 A/R 1094255-060 SHIM HORSESHOE 3X3X.06 THK WHEN INSTALLING TRUSSES TO HUB, SHIMMING MAY BE NECESSARY TO 26 177079 WASHER 3/4-.812 1.469 .134 SST 221 A/R 1094255-030 SHIM HORSESHOE 3X3X.03 THK ADJUST GAPS. FASTENERS HOLDING THE TRUSS TO THE UPPER FLANGE OF THE HUB SHOULD BE ATTACHED SNUG FIRST, LEAVING ANY GAP 72 85843 WASHER BETWEEN THE TRUSS AND THE LOWER HUB FLANGE. FILL THE GAP WITH 3/4- .812 1.469 .134 HRDN GALV 220 724281-0003 PANEL SPAR (CW) A COMBINATION OF SHIMS (FIND NO. 14, .03 INCH THK, AND FIND NO. 15, .06 INCH THK) TO MINIMIZE THE REMAINING GAP. AFTER SHIMMING EACH 384 177193 WASHER 1/2-.531 1.062 .109 SST 211 724281-0002 PANEL SPAR (CCW) 12 TRUSS ATTACHMENT, THE FASTENERS MAY BE TORQUED. EACH CORNER TRUSS IS LOCATED CW OF A HUB LIFT TAB. EACH SPAR TRUSS IS LOCATED 292 85842 WASHER CCW OF A HUB LIFT TAB. 1/2-.531 1.062 .109 HRDN GALV 210 724281-0001 PANEL **STANDARD** ONE INTERCOSTAL. ITEM 6. IS OMITTED FROM THE POSITION INDICATED TO 4 SCREW 12 1135217 3/4-10 X 2 3/4 CAP, SOC HD, SST 124 16 1101958-005 INTERCOSTAI 3RD RING ALLOW SWING CLEARANCE FOR THE ELEVATION ACTUATOR. 8 89873 BOLT REFER TO STUD DIMENSION CHART, SHEET 5, FOR PRESETTING STUD 3/4-10 X 2 3/4 HEX HD, GALV 123 16 1101958-004 INTERCOSTAI 2ND RING DIAGONAL DIMENSIONS PRIOR TO INSTALLING PANELS. 86315 BOLT 3/4-10 X 4 HEX HD. GALV 122 16 1101958-003 INTERCOSTAI 2ND RING LOWER DEPENDING ON THE ELECTRONICS IN THE HUB, THE ANTENNA WEIGHT WILL BE UP TO ABOUT 5300 LB [2400 KG] WITHOUT DE-ICING, AND UP TO 26 1094230 SCREW ABOUT 6800 LB [3080 KG] WITH DE-ICING. THE WEIGHTS OF INDIVIDUAL 3/4-10 X 2 3/4, HEX HD, SST 121 16 1101958-002 INTERCOSTAI 2ND RING UPPER COMPONENTS AND SUBASSEMBLIES ARE: 32 89830 BOLT 3/4-10 X 2 1/2 HEX HD, GALV 120 15 1101958-001 INTERCOSTAI 1ST RING LOWER 281945 BOLT 1/2-13 X 4.0 HEX HD GALV 114 LH TORSION 1102002 BRACE COMPONENT WEIGHT 8 1097660 BOLT 1/2-13 X 2.0, HEX HD, GALV 113 **BRACE RH TORSION** 1102001 HUB ASSEMBLY 2300 LB [1043 KG] 32 BOLT 89865 1/2-13 X 1 3/4 HEX HD, GALV 112 1097261 **TRUSS** SPAR FEED ASSEMBLY 61 LB [28 KG] SPAR/SUBREFLECTOR ASSY 85827 BOLT 107 LB [49 KG] 1/2-13 X 1 1/2 HEX HD. GALV 111 1097260 CORNER TRUSS TRUSS, NON-SPAR 56 LB [25 KG] 16 1094229 BOI T 1/2-13 X 1.0 HEX HD, GALV 110 1097259 **TRUSS** SIDE TRUSS, SPAR 61 LB [28 KG] NOMENCLATURE FIND QTY PART OR NOMENCLATURE FIND MATERIAL PART OR MATERIAL IDENTIFYING NO. OR DESCRIPTION **SPECIFICATION** IDENTIFYING NO. SPECIFICATION TORSION BRACE 14.2 LB [6.44 KG] PARTS LIST EXPORT CONTROL NOTICE

THIS DOCUMENT AND ANY ATTACHMENTS, APPENDICES, OR AMENDMENTS HERETO
MAY CONTAIN INFORMATION SUBJECT TO THE EXPORT ADMINISTRATION
FIGURATIONS. THIS INFORMATION MAY NOT BE EXPORTED. RE-EXPORTED, DIVERTED,
RELEASED, OR DISCLOSED TO FOREION NATIONALS ETHER WITHIN OR OUTSIDE THE
UNITED STATES WITHOUT FIRST COMPLYING WITH HE EXPORT LICENSING
REQUIREMENTS OF THE EXPORT ADMINISTRATION REGULATIONS STATES BY OF THE EXPORT ADMINISTRATION SAY REGULATIONS SHAY SEGULT IN OUTSIDE THE STATES BY OFFICE ON TIPOL LAWSON AND REGULATIONS MAY RESULT IN
CIVIL ADJORT CRIMINAL PENAL IES. THIS NOTICE MUST BE INCLUDED WITH ANY
REPRODUCED PORTION OF THIS DOCUMENT. INTERCOSTAL 5.1 LB [2.31 KG] PROPRIETARY NOTICE UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES AND APPLY
FTER FINISH OR PLATING, TOLERANCES ARE ViaSat 1725 BRECKINRIDGE PLAZA DULUTH, GA 30096 THESE DRAWINGS, LISTS OR SPECIFICATIONS ARE THE CONFIDENTIAL INFORMATION AND/OR TRADE SECRETS OF VIASAT IN, AND ISSUED IN STRICT CONFIDENCE EXCEPT AS AUTHORIZED BY VIASAT IN WRITING, THESE DRAWINGS, LISTS OR SPECIFICATIONS SHALL NOT BE REPRODUCED, RETRANSMITTED, USED FOR THE DESIGN MANUFACTURE OR SALE OF COLUMENT OR USED FOR ANY OTHER PURPOSE OTHER THAN EVALUATION. DATE(YYYY/MM/DD PANFI 79 LB [36 KG] D. FULLER 2010/02/26

X REF DES/FIND NO. QUANTITY

HOLE DIAMETER

.000-.250 +.004 -.001 -.001 -.001 -.001 -.001 -.001 -.001 -.001

DO NOT SCALE DRAWING

MAMASURENERGE RICHGIBS SSIRHGROAND.
A ILMAGRAHME SURFINGERS EXPERIPRA SHOULDE

BREAK SHARP EDGES AND CORNERS. 010 MA

THIRD ANGLE PROJECTION

- (+)

ELECTRONIC APPROVALS

ON FILE IN AGILE

CAD GENERATED DRAWING: SOLIDWORKS TEMPLATE P/N: 1055619 REV 002 SCALE: NONE WT:


10 LBS SHEET 1 OF 6


1102007 004


2-3


ASSY/INSTL DWG.


REFL 7.3 M KA (CHUB)











































Multiple Level Bill of Material Report ASSY, CASS FEED, KA-BAND, 4-PORT, CP 1111459 Rev002


Level	Ref Des	Part Description	Qty	Part Number
1	000	ASSY DWG, CASS FEED, KA-BAND, 4-PORT, CP	0	1111460
1	000	TEST PROCEDURE, CASS FEED ASSY, KA-BAND, 4-PORT, CP	0	1111461
1	000	SCHEMATIC,FD KA-BD,LNA&POL PLATE,WG KIT FOR CTRL PRGM TRK	0	1114740
1	000	SCHEMATIC,FD KA-BD,LNA&POL PLATE,WG KIT FOR DATA	0	1118622
l	001	ENCLOSURE, CIRCULAR FEED, KA-BAND	1	1099839
l	002	BEZEL, 9M KA-BAND	1	1001504
1	003	RADOME, 6.50 OD, REGAL, .005 THK, PTFE VIRGIN ETCHED TEFLON	1	1099974
_2		REGAL .005 X 24" X 24" PTFE VIRGIN ETCHED TEFLON	1	1050532
L	004	BRACKET, FEED MOUNT, KA-BAND, 4-PORT, CP, TRACKING	5	1098927
1	005	PLATE # 1, FEED MOUNT, KA-BAND, 4-PORT, CP, TRACKING	1	1098928
l	006	PLATE # 2, FEED MOUNT, KA-BAND, 4-PORT, CP, TRACKING	2	1098929
1	007	BRACKET, POWER CONNECTOR, KA-BAND FEED	1	1110653
l	008	RING O 5.737 ID X 5.943 OD X .103W SILICONE	1	1002364
L	030	NOZZLE, FEED BLOWER	1	1093581
l	031	BRACKET, FITTING, TOP, NOZZLE	1	1098548
L	032	BRACKET, FITTING, BOTTOM, NOZZLE	1	1098549
l	033	BRACKET, BOTTOM, NOZZLE	1	1099846
l	110	SCREW 4-40 X 3/8 F HD,82 DEG,SST	12	72321
L	120	SCREW 6-32 X 5/8 SOC CAP SST	2	72377
1	121	SCREW 6-32 X 3/4 SOC CAP SST	8	72380
l	140	SCREW 10-32 X 5/8 HEX SOC HD CAP SST	37	72428
l	141	SCREW 10-32 X 3/4 HEX SOC HD CAP SST	15	72432
1	151	SCREW 1/4-20 X 5/8 CAP HEX SST	5	171511
1	152	SCREW 1/4-20 X 7/8 CAP,HEX HD,AUS SST	5	88422
1	170	BOLT 3/8-16X1 1/4 HEXHD GALV	8	281932
1	220	WASHER-# 6156 .312 .035 AUS SST	12	73270
1	221	WASHER # 6 LOCK, SPLIT, SST	10	174555
1	240	WASHER-#10219 .500 .049 AUS SST	17	73275
l	241	WASHER # 10 LOCK, SPLIT,SST	10	174557
L	242	WASHER # 10 SEALING .200 ID 1/2 OD SST	42	725337-0001
1	250	WASHER,1/4 FLAT,.281 .625 .065 AUS SST,ROHS	11	76917
l	251	WASHER, SEALING, .26 ID X 1/2 OD SST	5	1013435
1	270	WASHER- 3/8438 1.000 .083 HRDN GALV	16	85841
1	320	NUT 6-32 UNC-2B,PLAIN-HEX,SST	2	75446
1	340	NUT,10-32 UNF-2B,PLAIN-HEX,SST,ROHS	5	71503
1	350	NUT 1/4-20 UNC-2B PLAIN-HEX SST	6	86374


Multiple Level Bill of Material Report ASSY, CASS FEED, KA-BAND, 4-PORT, CP 1111459 Rev002


Level	Ref Des	Part Description	Qty	Part Number
_1	370	NUT 3/8-16 UNC-2B HVY HEX HI-STR GALV	8	85837
_1	400	SEALANT SILIC RUB RTV NON-CRSV,WHTE,3 OZ	0.1	86520
_1	A001	ASSY, HORN AND FEED NETWORK, KA-BAND, 4-PORT, CP	1	1111455
2	000	CORRUGATED HORN, TRACKING, 9M KA	0	727212-0001
2	000	SPECIFICATION, FEED NETWORK, 4 PORT CP, KA-BAND	0	1111456
_1	A002	KIT, PRESSURE TESTING AND SHIPPING, KA-BAND FEED	1	1111483
_2	009	WAVEGUIDE GASKET WR42 PRESSURE SILICONE	4	420410
_2	111	SCREW,4-40 X 7/16,SKT HD,SS, PASSIVATED	8	1033033
_2	112	SCREW 4-40 X 5/8 PAN HD,SST	8	72334
_2	210	WASHER-# 4125 .250 .022 AUS SST	16	73266
_2	211	WASHER # 4 LOCK, SPLIT, SST	16	174554
_2	501	HOSE, LOW TEMP, ETHER-BASE, 0.25 ID, 1/32 WALL	25.5	1013460
_2	502	HOSE, LOW TEMP, ETHER-BASED, 5/16 ID, 1/16 WALL	5.5	1013461
_2	503	COUPLING 1/8" SOCKET W/SHUT OFF VALVE	2	719640-0001
_2	504	FITTING, 5/16 HOSE BARB, 1/8 PIPE	1	1013854
_2	505	FTG,1/4 HOSE,BARB,1/8 F,PIPE	1	1016738
_2	506	CLPG PLUG 1/8" NPT MALE QCK DISCNCT W/SHUTOFF	1	1005537
_2	507	VLVE PRESSURE RELIEF 0.6 PSI 1/8 NPT BRS	1	719613-0001
_2	508	PLATE, COVER, WR34/42 FLANGE	2	1047267
_2	509	FAB PART, PLATE # 2, WG PRESSURIZATION	2	1016699
_2	510	CLAMP HOSE ADJ 7/32 - 5/8 DIA ALL SST	1	1049822
_2	512	TAPE,TEFLON,ANTISEIZE,.0035 THK,1/2 IN W X 520 IN L	0.1	86369














Multiple Level Bill of Material Report ASSY, FEED, KA-BAND, 4-PORT, CP, TRACKING 1093281 Rev006

Level	Ref Des	Part Description	Qty	Part Number
_1	000	ASSY DWG, FEED, KA-BAND, 4-PORT, CP, TRACKING	0	1091781
_1	000	TEST PROCEDURE, FEED ASSY, KA-BAND, CP	0	1100589
_1	001	ENCLOSURE, CIRCULAR FEED, KA-BAND	1	1099839
_1	002	BEZEL, 9M KA-BAND	1	1001504
_1	003	RADOME, 6.50 OD, REGAL, .005 THK, PTFE VIRGIN ETCHED TEFLON	1	1099974
_2		REGAL .005 X 24" X 24" PTFE VIRGIN ETCHED TEFLON	1	1050532
_1	004	BRACKET, FEED MOUNT, KA-BAND, 4-PORT, CP, TRACKING	5	1098927
1	005	PLATE # 1, FEED MOUNT, KA-BAND, 4-PORT, CP, TRACKING	1	1098928
_1	006	PLATE # 2, FEED MOUNT, KA-BAND, 4-PORT, CP, TRACKING	2	1098929
1	007	BRACKET, POWER CONNECTOR, KA-BAND FEED	1	1110653
_1	030	NOZZLE, FEED BLOWER	1	1093581
_1	031	BRACKET, FITTING, TOP, NOZZLE	1	1098548
_1	032	BRACKET, FITTING, BOTTOM, NOZZLE	1	1098549
_1	033	BRACKET, BOTTOM, NOZZLE	1	1099846
_1	110	SCREW 4-40 X 3/8 F HD,82 DEG,SST	12	72321
1	111	SCREW,4-40 X 7/16,SKT HD,SS, PASSIVATED	12	1033033
1	112	SCREW 4-40 X 5/8 PAN HD,SST	8	72334
_1	113	SCREW 4-40 X 3/4 SOC CAP SST	4	72335
_1	120	SCREW 6-32 X 5/8 SOC CAP SST	2	72377
_1	121	SCREW 6-32 X 3/4 SOC CAP SST	8	72380
_1	130	SCREW 10-32 X 5/8 HEX SOC HD CAP SST	5	72428
_1	131	SCREW 10-32 X 3/4 HEX SOC HD CAP SST	15	72432
_1	141	SCREW 1/4-20 X 5/8 CAP HEX SST	5	171511
_1	142	SCREW 1/4-20 X 7/8 CAP,HEX HD,AUS SST	5	88422
_1	150	BOLT 3/8-16X1 1/4 HEXHD GALV	8	281932
_1	210	WASHER-# 4125 .250 .022 AUS SST	32	73266
_1	211	WASHER # 4 LOCK, SPLIT, SST	24	174554
1	220	WASHER-# 6156 .312 .035 AUS SST	12	73270
1	221	WASHER # 6 LOCK, SPLIT, SST	10	174555
1	230	WASHER-#10219 .500 .049 AUS SST	17	73275
1	231	WASHER # 10 LOCK, SPLIT,SST	10	174557
1	232	WASHER # 10 SEALING .200 ID 1/2 OD SST	38	725337-0001
1	240	WASHER,1/4 FLAT,.281 .625 .065 AUS SST,ROHS	11	76917
1	241	WASHER, SEALING, .26 ID X 1/2 OD SST	5	1013435
_1	250	WASHER- 3/8438 1.000 .083 HRDN GALV	16	85841
1	310	NUT 4-40 UNC-2B,PLAIN-HEX,SST	8	71494

Multiple Level Bill of Material Report ASSY, FEED, KA-BAND, 4-PORT, CP, TRACKING 1093281 Rev006

Level	Ref Des	Part Description	Qty	Part Number
_1	320	NUT 6-32 UNC-2B,PLAIN-HEX,SST	2	75446
_1	330	NUT,10-32 UNF-2B,PLAIN-HEX,SST,ROHS	5	71503
_1	340	NUT 1/4-20 UNC-2B PLAIN-HEX SST	6	86374
_1	350	NUT 3/8-16 UNC-2B HVY HEX HI-STR GALV	8	85837
_1	400	SEALANT SILIC RUB RTV NON-CRSV,WHTE,3 OZ	1	86520
_1	500	RING O 5.737 ID X 5.943 OD X .103W SILICONE	1	1002364
_1	A001	ASSY, FEED RF, 9.1 M TRKG, CP	1	1094186
_2		CONFIGURATION, FEED RF, 9.1M TRKG, CP	0	1095070
_2		SPEC, FEED NETWORK, 4-PORT CP, TRACKING, KA-BAND	0	1095072
_2		CORRUGATED HORN, TRACKING, 9M KA	0	727212-0001
2		INTFC DWG, FEED NETWORK, 4-PORT CP, TRACKING, KA-BAND	0	1095067
_1	A002	KIT, PRESSURIZATION, KA-BAND TRACKING FEED	1	1102509
2	601	HOSE, LOW TEMP, ETHER-BASE, 0.25 ID, 1/32 WALL	25.5	1013460
2	602	HOSE, LOW TEMP, ETHER-BASED, 5/16 ID, 1/16 WALL	5.5	1013461
2	603	COUPLING 1/8" SOCKET W/SHUT OFF VALVE	2	719640-0001
_2	604	FITTING, 5/16 HOSE BARB, 1/8 PIPE	1	1013854
_2	605	FTG,1/4 HOSE,BARB,1/8 F,PIPE	1	1016738
_2	606	CLPG PLUG 1/8" NPT MALE QCK DISCNCT W/SHUTOFF	1	1005537
2	607	VLVE PRESSURE RELIEF 0.6 PSI 1/8 NPT BRS	1	719613-0001
_2	608	PLATE, COVER, WR34/42 FLANGE	4	1047267
_2	609	FAB PART, PLATE # 2, WG PRESSURIZATION	2	1016699
2	610	CLAMP HOSE ADJ 7/32 - 5/8 DIA ALL SST	1	1049822
_2	611	WAVEGUIDE GASKET WR42 PRESSURE SILICONE	6	420410
_2	612	TAPE,TEFLON,ANTISEIZE,.0035 THK,1/2 IN W X 520 IN L	0.1	86369